

ŘAD	OZNAČENÍ BODU	X	Y
>	V1 - výstup z ČSOV	-695454.630	-1017529.968
	V2	-695455.233	-1017533.002
	V3	-695458.793	-1017541.925
	V4	-695532.944	-1017541.013
	V5	-695571.384	-1017537.923
	V6	-695651.314	-1017536.241
	V7	-695698.960	-1017540.453
	V8	-695734.123	-1017549.106
	V9	-695767.554	-1017563.771
	V10	-695827.041	-1017598.540
	V11	-695917.741	-1017654.945
	V12	-695968.248	-1017686.891
	V13	-696071.609	-1017750.661
	V14	-696122.491	-1017780.129
	V15	-696176.551	-1017803.721
	V16	-696224.537	-1017818.199
	V17	-696249.453	-1017823.686
	V18	-696270.805	-1017827.454
	V19	-696380.390	-1017838.572
	V20	-696456.838	-1017845.781
	V21	-696534.277	-1017855.608
	V22	-696624.482	-1017864.595
	V23	-696690.561	-1017872.791
	V24	-696794.421	-1017882.923
	V25	-696866.154	-1017889.820
	V26	-696986.459	-1017902.074
	napojení na výtlačk ČOV Semčice	-696996.107	-1017889.182